

FIG. 1 is a perspective view of a portable electronic device 100. The device includes a main body 101 and a hinged cover 102. The cover 102 is shown in an open position, revealing the internal components of the device. The cover 102 is connected to the main body 101 by a hinge mechanism 103. The hinge mechanism 103 includes a hinge pin 104 and a hinge bracket 105. The cover 102 also includes a latch 106 and a latch pin 107. The main body 101 includes a display screen 108 and a keypad 109. The device also includes a connector 110, which is connected to the main body 101 by a cable 111. The connector 110 includes a plug 112 and a socket 113. The plug 112 is shown inserted into the socket 113. The device is shown in a perspective view, with the cover 102 open and the main body 101 facing the viewer.




FIG.2




FIG.3




FIG.4




FIG. 5




FIG.6




FIG.7





FIG.9






FIG.11




FIG.12




FIG.13




FIG.14




FIG.15




FIG. 16




FIG. 17




FIG. 18




FIG.19




FIG.20




FIG. 22




FIG.23




FIG.24




FIG.25




FIG.26




FIG.27




FIG.28




FIG.29




FIG.30




FIG.31

